

### Instruction for Measuring Windows

The trim on the outside of the window frame is referred to as the *Blind Stop*. This holds the sash in place. You install the interior window inside that stop this the *Rough Opening*.

Measure the width of the window frame at three places (1, 2, & 3) and height in three places (4, 5 & 6). This is the *Rough Opening*.

